



## TROUBLE SHOOTING

Minute hand tracking too fast



Check position of base gear. The base gear should be flush with base and not touching minute wheel.

Hour hand not moving



Check position of hour stop and hour advance. The hour stop and hour advance should be engaged with teeth on hour ratchet.

Save these instructions for future reference.



# MASTER MOTION™ CLOCK



## LIMITED WARRANTY

Your Arrow Master Motion Clock is warranted against defects in materials or workmanship for 90 days from the date of the original purchase. Any clock which, because of a manufacturing mistake, malfunctions or proves to be defective within the 90 day warranty period will be repaired or replaced, at Arrow's option, and at no charge to you, provided it is returned to Arrow with proof of date of original purchase.

*This warranty does not cover incidental or consequential damage including injury or damage to persons or property caused by the use, abuse, misuse, failure to comply with unpacking or operating instructions of the clock.*

Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

For repair or replacement under this warranty please return your clock with proof of date of original purchase to us.

If you have any questions about or problems with your Master Motion™ Clock, call our Tech-Tip Department at 1-800-525-7563.

ARROW INDUSTRIES, 1295 H STREET, PENROSE, CO 81240 USA